

# **System II Liquid to Liquid Heat Exchanger**

NESLAB Manual P/N 002179  
Rev. 06/05/97

## **Instruction and Operation Manual**



# System II Liquid to Liquid Heat Exchanger Instruction and Operation Manual

## Table of Contents

<b>PREFACE</b>	
	Compliance ..... 3
	Unpacking ..... 3
	Warranty ..... 3
	After-sale Support ..... 3
<b>SECTION I</b>	
<b>Safety</b>	
	Warnings ..... 4
<b>SECTION II</b>	
<b>General Information</b>	
	Description ..... 5
	Specifications ..... 5
<b>SECTION III</b>	
<b>Installation</b>	
	Site ..... 7
	Facility Water Requirements ..... 7
	Electrical Requirements ..... 8
	Plumbing Requirements ..... 8
	Fluids ..... 9
	Water Quality Standards and Recommendations ..... 9
	Filling Requirements ..... 10
<b>SECTION IV</b>	
<b>Operation</b>	
	Start Up ..... 11
	REMOTE/LOCAL Switch (Optional) ..... 11
	Temperature Adjustment ..... 11
<b>SECTION V</b>	
<b>Special Features</b>	
	Low Fluid Level Monitor ..... 12
	High Temperature Monitor ..... 12
	INTERLOCK Contacts ..... 12
	Pressure Relief Valve ..... 13
<b>SECTION VI</b>	
<b>Maintenance</b>	
	Service Contracts ..... 14
	Cleaning ..... 14
	Algae ..... 14
	Pump Strainer ..... 14
	Facility Water Strainer ..... 15
<b>SECTION VII</b>	
<b>Troubleshooting</b>	
	Checklist ..... 16
	Service Assistance ..... 16
<b>SECTION VIII</b>	
<b>Warranty</b>	..... 17

## System II Quick Reference Operating Procedures

### Installation

The unit has a heat exchanger, recirculation pump, stainless steel reservoir and a temperature controller. The unit should be located in an area with easy access to a cooling water source and a drain.

Cooling capacity is based the temperature of the cooling water supply and the cooling fluid supplied to your application.

Make sure the voltage of the power source meets the specified voltage,  $\pm 10\%$ .

The plumbing connections are located on the rear of the unit and are labelled COOLING WATER and PROCESS WATER. These connections are  $\frac{1}{2}$  inch FPT. Connect the COOLING WATER connections to the cooling water supply. Connect the PROCESS WATER connections to your application.

To fill the reservoir remove the reservoir access cover and fill the reservoir with clean cooling fluid to within 1 inch of the top.

Tap water is the recommended fluid for operation from  $+8^{\circ}\text{C}$ . Below  $+8^{\circ}\text{C}$ , a non-freezing fluid must be used. A mixture of tap water and laboratory grade ethylene glycol is suggested.

### Operation

Before starting the unit, double check all electrical and plumbing connections. Make sure the circulating system has been filled with cooling fluid.

Ensure that the facility water is turned on.

To start the unit, place the OFF/ON/START Switch to the START position. The recirculation pump starts and the POWER ON lamp illuminates.

The TEMPERATURE gauge on the front of the unit indicates the temperature of the fluid in the reservoir. The temperature of the cooling fluid is adjusted by turning the recessed valve screw located on top of the unit.

### Periodic Maintenance

Periodically inspect the reservoir fluid. If cleaning is necessary, flush the reservoir with a cleaning fluid compatible with the circulating system and the cooling fluid.

Units are equipped with pump strainers. If debris is in the system, the strainer will prevent the material from being drawn into the pump and damaging the pump vanes.

After initial installation, the strainer may become clogged. The strainer must be cleaned after the first week of installation. After this first cleaning, a monthly visual inspection is recommended. After several months, the frequency of cleaning will be established.

Before cleaning, disconnect the power cord from the power source and drain the reservoir.

## Preface

### Compliance

Products tested and found to be in compliance with the requirements defined in the EMC standards defined by 89/336/EEC as well as Low Voltage Directive (LVD) 73/23/EEC can be identified by the CE label on the rear of the unit. The testing has demonstrated compliance with the following directives:

LVD, 73/23/EEC	Complies with UL 3101-1:93
EMC, 89/336/EEC	EN 55011, Class A Verification EN 50082-1:1992 IEC 1000-4-2:1995 IEC 1000-4-3:1994 IEC 1000-4-4:1995

For any additional information refer to the Letter of Compliance that shipped with the unit (Declaration of Conformity).

### Unpacking

Retain all cartons and packing material until the unit is operated and found to be in good condition. If the unit shows external or internal damage, or does not operate properly, contact the transportation company and file a damage claim. Under ICC regulations, this is your responsibility.

### Warranty

Units have a one year warranty against defective parts and workmanship from date of shipment. See back page for more details.

### After-sale Support

NESLAB is committed to customer service both during and after the sale. If you have questions concerning the operation of your unit, contact our Sales Department. If your unit fails to operate properly, or if you have questions concerning spare parts or Service Contracts, contact our Customer Service Department. Before calling, please obtain the following information from the unit's serial number label:

- *BOM number* \_\_\_\_\_

- *Serial number* \_\_\_\_\_

## Section I Safety

### Warnings

Make sure you read and understand all instructions and safety precautions listed in this manual before installing or operating your unit. If you have any questions concerning the operation of your unit or the information in this manual, contact our Sales Department (see After-sale Support).

**Performance of installation, operation, or maintenance procedures other than those described in this manual may result in a hazardous situation and may void the manufacturer's warranty.**

**Observe all warning labels.**

**Never remove warning labels.**

**Never operate damaged or leaking equipment.**

**Never operate the unit without cooling fluid in the reservoir.**

**Always turn off the unit and disconnect the line cord from the power source before performing any service or maintenance procedures, or before moving the unit.**

**Always empty the reservoir before moving the unit.**

**Never operate equipment with damaged line cords.**

**Refer service and repairs to a qualified technician.**

In addition to the safety warnings listed above, warnings are posted throughout the manual. These warnings are designated by an exclamation mark inside an equilateral triangle with text highlighted in bold print. Read and follow these important instructions. Failure to observe these instructions can result in permanent damage to the unit, significant property damage, or personal injury or death.

## Section II General Information

### Description

The System II Liquid to Liquid Heat Exchanger uses building recirculating or tap water as the secondary cooling medium to remove heat from the cooling fluid in the closed circulation loop.

The unit consists of a heat exchanger, recirculation pump, stainless steel reservoir, and a temperature controller.

The System II is available with two different plumbing configurations: single circulation loop, and dual circulation loop.

The single circulation loop unit has either two positive displacement pumps (PD-2) or a single turbine pump (TU-3), plumbed to a single inlet and outlet. The front panel switches and gauges correspond to this loop.

The dual circulation loop unit has two positive displacement pumps (PD-2), each plumbed to a separate inlet and outlet (A and B). The front panel switches and gauges labelled A, correspond with loop A. Front panel switches and gauges labelled B, correspond with loop B.

### Specifications


Temperature Range

+10°C to +30°C


Temperature Stability<sup>1</sup>

±1.0°C


Cooling Capacity<sup>1,2</sup>



**TU-3 Pumping Capacity<sup>1</sup>**



**PD-2 Pump Capacity<sup>1</sup>**



**Reservoir Volume**

*Gallons*

1.75

*Liters*

6.6

**Unit Dimensions**

*(H x W x D)*

*Inches*

30<sup>1</sup>/<sub>8</sub> x 16<sup>1</sup>/<sub>4</sub> x 20<sup>1</sup>/<sub>8</sub>

*Centimeters*

76.5 x 41.3 x 51.1

1. Specifications listed are for a standard unit, +20°C fluid temperature, with tap water as the cooling fluid.
2. Cooling capacity is based on a 10°C difference between the temperature of the cooling water supply (house water) and the cooling fluid supplied to the instrument being cooled (see Section III, Facility Water Requirements). Pressure differential is required from house water.

## Section III Installation

### Site

The unit should be placed in a location with easy access to a cooling water source and a drain.




**Never place the unit in a location where excessive heat, moisture, or corrosive materials are present.**

### Facility Water Requirements

Refer to the Cooling Capacity chart in Section II, Specifications. The flow rate of the cooling water supply must meet or exceed these requirements for the unit to operate at its full rated capacity. If the cooling water does not meet these standards, the cooling capacity will derate. The chart is based on a 10°C difference between the temperature of the cooling water supply (house water) and the cooling fluid supplied to the instrument being cooled.

As the heat load increases, the required flow rate of the cooling water supply increases. For example, if the heat load is 12 kilowatts, only 2.75 gallons per minute is required to remove the heat. However, if the heat load is 30 kilowatts, about 8.5 gallons per minute is required.

The chart below shows the approximate pressure drop through copper or plastic tubing at given flow rates.





## **Electrical Requirements**

Refer to the serial number label on the rear of the unit to identify the specific electrical requirements of your unit.

Ensure the voltage of the power source meets the specified voltage,  $\pm 10\%$ .

The unit construction provides extra protection against the risk of electric shock by grounding appropriate metal parts. The extra protection may not function unless the power cord is connected to a properly grounded outlet. It is your responsibility to assure a proper ground connection is provided.

## **Plumbing Requirements**

Before installing the unit to an instrument that previously used tap water as a cooling fluid, flush the instrument several times to remove any rust or scale that has built up. The manufacturer of the instrument should be able to recommend a cleaning fluid for their equipment.

The plumbing connections are located on the rear of the unit and are labelled COOLING WATER and PROCESS WATER. The COOLING WATER connections are  $\frac{1}{2}$  inch FPT. The PROCESS WATER connections are  $\frac{3}{4}$  inch MPT.

Connect the COOLING WATER connections to the cooling water supply.

Connect the PROCESS WATER connections to the instrument being cooled.

Flexible tubing, if used, should be of heavy wall or reinforced construction. All tubing should be rated to withstand 80 psi at  $+35^{\circ}\text{C}$ . Make sure all tubing connections are securely clamped. Avoid running tubing near radiators, hot water pipes, etc. If substantial lengths of tubing are necessary, insulation may be required to prevent loss of cooling capacity.

Tubing and insulation are available from NESLAB. Contact our Sales Department for more information (see Preface, After-sale Support).

It is important to keep the distance between the unit and the instrument being cooled as short as possible, and to use the largest diameter tubing practical. Tubing should be straight and without bends. If diameter reductions must be made, they should be made at the inlet and outlet of the instrument being cooled, not at the unit.

If substantial lengths of cooling lines are required, they should be pre-filled with cooling fluid before connecting them to the unit.

## Fluids

Refer to the Water Quality Standards and Recommendations section.

Tap water is the recommended fluid for operation above 8°C.

Below +8°C, a non-freezing solution is required. A 50/50 mixture of laboratory grade ethylene glycol and water is suggested.



**Do not use automobile anti-freeze. Commercial anti-freeze contains silicates that can damage the pump seals. Use of automobile anti-freeze will void the manufacturer's warranty.**



**Never use flammable or corrosive fluids with this unit.**

## Water Quality Standards and Recommendations

	Permissible(PPM)	Desirable(PPM)
<b>Microbiologicals</b>		
(algae,bacteria,fungi)	0	0
<b>Inorganic Chemicals</b>		
Calcium	<40	0.6
Chloride	250	<25
Copper	1.3	1.0
Iron	0.3	<0.1
Lead	0.015	0
Magnesium	<12	0.1
Manganese	0.05	<0.03
Nitrates\Nitrites	10 as N	0
Potassium	<20	0.3
Silicate	25	<1.0
Sodium	<20	0.3
Sulfate	250	<50
Hardness	17	<0.05
Total Dissolved Solids	50	10
<b>Other Parameters</b>		
pH	6.5-8.5	7-8
Resistivity	0.01*	0.05-0.1*

\* Megohm-Cm (Compensated at 25C)


Unfavorably high total ionized solids (TIS) can accelerate the rate of galvanic corrosion. These contaminants can function as electrolytes which increase the potential for galvanic cell corrosion and lead to localized corrosion such as pitting which can be observed at the studs and on the outside surface of cooling coils. Eventually, the pitting will become so extensive that the coil will leak refrigerant into the water reservoir.

As an example, raw water in the United States averages 171 ppm (as NaCl). The recommended level for use in a water system is between 0.5 to 5.0 ppm (as NaCl).

Recommendation: Initially fill the tank with distilled/deionized water. Do not use untreated tap water as the total ionized solids level may be too high.

Maintain this water quality at a resistivity of between 1 to 10 megohm-cm (compensated at 25°C) by using a purification system. Although the initial fill may be as high as 10 megohm-cm (compensated at 25°C), the desired level for long time usage is 1 to 3 megohm-cm (compensated at 25°C).

The above two recommendations will reduce the electrolytic potential of the water and prevent or reduce the galvanic corrosion observed.



Water Quality Considerations

## Filling Requirements

The reservoir access cover is located on top of the unit. Fill the reservoir to within 1 inch of the top. Keep extra cooling fluid on hand until the entire system (the System II, the instrument being cooled and the tubing that connects them) is filled.

## Section IV Operation

### Start Up

Before starting the unit, check all electrical and plumbing connections and make sure the circulating system has been properly filled with cooling fluid.

Ensure the facility water is turned on.

To start, momentarily place the OFF/ON/START switch in the START position. The recirculation pump will start and the POWER ON lamp will light.

If the unit does not continue to run when the OFF/ON/START switch is released, check the fluid level in the reservoir. The float switch in the reservoir prevents the unit from operating if the fluid level in the reservoir is below the operating level. If the fluid level is low, "top off" the reservoir.

### REMOTE/LOCAL Switch (Optional)

To enable the remote on/off function, place the REMOTE/LOCAL switch to REMOTE. A 24 volt AC signal applied to the 6 pin connector will start the unit. The unit will stop when the signal is removed. When the REMOTE/LOCAL switch is in the REMOTE position, the unit can not be started locally.

Pin connections:

Pin 1	Ground.
Pins 2 and 3	A 24 volt AC signal applied to these pins will start the unit when the REMOTE/LOCAL switch is in the REMOTE position.
Pin 4	Not used.
Pin 5 and 6	These pins are connected to normally open contacts. The contacts are closed when the unit is running.

### Temperature Adjustment

A control valve, located in the COOLING WATER INLET line, regulates the flow rate of the cooling water supply as it enters the unit. The valve regulates the flow rate based on the heat load.

The temperature of the cooling fluid is adjusted by turning the recessed valve screw located on top of the unit. Adjust the screw by inserting a screwdriver through the hole in the top. Turn the screw counterclockwise to increase the temperature of the cooling fluid, clockwise to decrease the temperature.

The TEMPERATURE gauge on the front of the unit indicates the temperature of the fluid in the reservoir.

When selecting an operating temperature, remember that the lowest achievable temperature is a function of the available flow rate, the temperature of the cooling water supply, the heat load and the cooling fluid.

## Section V Special Features

### Low Fluid Level Monitor

The low fluid level monitor is connected to a float switch in the reservoir. A low fluid level fault occurs when the cooling fluid in the reservoir drops below the operating level.

In the event of a low fluid level fault, the unit will shut down, and the INTERLOCK contacts will open. For proper operation, the cause of the fault must be identified and corrected before the unit can be restarted, the fluid level must be returned to the proper operating level.

### High Temperature Monitor

The high temperature monitor (HTC) is connected to a sensor that monitors the cooling fluid temperature as it exits the heat exchanger. The monitor protects the system from exposure to excessively hot cooling fluid. A temperature fault occurs when the cooling fluid temperature exceeds the set temperature limit.

In the event of a high temperature fault, the unit will shut down, and the INTERLOCK contacts will open. The cause of the fault must be identified and corrected before the unit can be restarted.

The monitor is not pre-set and must be adjusted during initial installation. The monitor is located on the rear of the unit.

A slotted adjustment screw is located in the center of the monitor. A temperature range scale surrounds the adjustment screw. The temperature scale is in °F.

To adjust the monitor, turn the adjustment screw until the pointer on the temperature scale corresponds to the desired temperature limit. A temperature limit approximately 50°F higher than the operating temperature is recommended.

### INTERLOCK Contacts

A set of relay contacts is connected to a receptacle on the front panel. The contacts are rated 15A, 250V. This is not a power inlet or outlet. The receptacle is isolated from the circuitry. Its ground pin is connected to the chassis. The contacts are normally open: they are closed during normal operation and open when the unit is turned off or when a fault occurs.

## **Pressure Relief Valve**

The pressure relief valve establishes the maximum operating pressure of the unit. If the pressure of the fluid leaving the pump exceeds the valve setting, the relief valve will bypass the fluid within the unit to relieve the pressure. The relief valve does not determine the actual operating pressure; the operating pressure of the system is determined by the back pressure of the connected equipment and the setting of the flow control.

If adjustment is necessary, contact our Customer Service Department.

For applications requiring maximum pressure less than 55 psi, a retrofittable External Pressure Reducer (EPR) is available. An EPR allows operating pressures of 10 to 50 psi. Contact our Sales Department for more information (see Preface, After-sale Support). Before calling please obtain the following information:

*Part number*

*Serial number*

## Section VI Maintenance

### Service Contracts

NESLAB offers on-site Service Contracts that are designed to provide .... extended life and minimal down-time for your unit. For more information, contact our Service Department (see Preface, After-sale Support).

### Cleaning

Periodically inspect the reservoir. If cleaning is necessary, flush the reservoir with a cleaning fluid compatible with the circulating system and the cooling fluid.

### Algae

To restrict the growth of algae in the reservoir, it is recommended that the reservoir cover be kept in place and that all circulation lines be opaque. This will eliminate the entrance of light which is required for the growth of most common algae.

NESLAB recommends the use of Chloramine-T, one gram per gallon.

### Pump Strainer

A wire mesh screen is located on the pump suction line.

If debris is in the system, the strainer will prevent the material from being drawn into the pump and damaging the pump vanes.

After initial installation, the strainer may become clogged with debris and scale. Therefore, the strainers must be cleaned after the first week of installation. Before cleaning, disconnect the line cord from the power source and drain the reservoir.


Unscrew the strainer and rinse it with water. Replace the strainer. After this first cleaning, a monthly visual inspection is recommended. After several months, the frequency of cleaning will be established.

#### TU-3 Pumps

The strainer for units equipped with a TU-3 pumps is located inside the reservoir, directly under the reservoir access cover.


#### PD-2 Pumps

Remove the unit's wrapper. The strainer for units equipped with PD-2 pumps is located in each pump's suction line (under the hex nut).



PD-2 pump motors requires pump lubrication. These motors use sleeve type bearings with large oil reservoirs. Oiling instructions are generally posted on each motor. In the absence of legible lubrication instructions, add approximately 30 to 35 drops of SAE 20 non-detergent oil to each bearing on the following schedule (SAE 20 = 142 CS viscosity):

Duty Cycle	Oiling Frequency
Continuous	Every year
Intermittent	Every 2 years
Occasional	Every 5 years



### **Facility Water Strainer (Optional)**

The facility water strainer is a user-installed basket strainer on the FACILITY WATER inlet. Clean the strainer when it becomes clogged or dirty.

Disconnect the power cord from the power source and turn off the facility water. Place a container under the strainer to collect any water spills out of the basket when it is removed.

Unscrew the clear plastic basket. Remove the screen and rinse it with water. Replace the screen and the basket.



## Section VII Troubleshooting

### Checklist

#### **Unit will not run**

Make sure the voltage of the power source meets the specified voltage,  $\pm 10\%$ . Refer to the serial number on the rear of the unit for the specific electrical requirements of your unit.

On units with a REMOTE/LOCAL switch, ensure the switch is in the correct position.

#### **Unit runs when OFF/ON/START button is in START position, but stops when button is released.**

Hold switch in START position for longer period of time.

Check for proper reservoir level. The float switch in the reservoir prevents the unit from operating if the fluid level in the reservoir is below the operating level. If the fluid level is low, "top off" the reservoir and restart the unit.

Make sure the high temperature monitor is set higher than the temperature of the cooling fluid.

Check the fuse on the circuit board inside the control box. The fuse is 0.5 Amp 250 V slow-blow.

#### **Unit runs for a short period, then stops.**

Check the fluid level in the reservoir. If it is low, check the system for leaks.

Make sure the heat load is not greater than the cooling capacity of the unit (see Section II, Cooling Capacity).

Make sure the cooling water supply meets the requirements outlined in Section III, Facility Water Requirements.

A possible power interruption has occurred, causing the "latch" relay to unlatch. Attempt to restart.

### Service Assistance

If, after following these troubleshooting steps, your unit fails to operate properly, contact our Service Department for assistance (see Preface, After-sale Support). Before calling please obtain the following information:

*Part number*

*Serial number*

*Voltage of unit*

*Voltage of power source*

*Temperature at which the problem occurs*

*Temperature, pressure, and flow rate of cooling water supply*

Our Service Department can provide you with a wiring diagram and a complete list of spare parts for your unit.

## WARRANTY

NESLAB Instruments, Inc. warrants for 12 months from date of shipment any NESLAB unit according to the following terms.

Any part of the unit manufactured or supplied by NESLAB and found in the reasonable judgment of NESLAB to be defective in material or workmanship will be repaired at an authorized NESLAB Repair Depot without charge for parts or labor. The unit, including any defective part must be returned to an authorized NESLAB Repair Depot within the warranty period. The expense of returning the unit to the authorized NESLAB Repair Depot for warranty service will be paid for by the buyer. NESLAB's responsibility in respect to warranty claims is limited to performing the required repairs or replacements, and no claim of breach of warranty shall be cause for cancellation or rescission of the contract of sales of any unit.

With respect to units that qualify for field service repairs, NESLAB's responsibility is limited to the component parts necessary for the repair and the labor that is required on site to perform the repair. Any travel labor or mileage charges are the financial responsibility of the buyer.

The buyer shall be responsible for any evaluation or warranty service call (including labor charges) if no defects are found with the NESLAB product.

This warranty does not cover any unit that has been subject to misuse, neglect, or accident. This warranty does not apply to any damage to the unit that is the result of improper installation or maintenance, or to any unit that has been operated or maintained in any way contrary to the operating or maintenance instructions specified in NESLAB's Instruction and Operation Manual. This warranty does not cover any unit that has been altered or modified so as to change its intended use.

In addition, this warranty does not extend to repairs made by the use of parts, accessories, or fluids which are either incompatible with the unit or adversely affect its operation, performance, or durability.

NESLAB reserves the right to change or improve the design of any unit without assuming any obligation to modify any unit previously manufactured.

THE FOREGOING EXPRESS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

NESLAB'S OBLIGATION UNDER THIS WARRANTY IS STRICTLY AND EXCLUSIVELY LIMITED TO THE REPAIR OR REPLACEMENT OF DEFECTIVE COMPONENT PARTS AND NESLAB DOES NOT ASSUME OR AUTHORIZE ANYONE TO ASSUME FOR IT ANY OTHER OBLIGATION.

NESLAB ASSUMES NO RESPONSIBILITY FOR INCIDENTAL, CONSEQUENTIAL, OR OTHER DAMAGES INCLUDING, BUT NOT LIMITED TO LOSS OR DAMAGE TO PROPERTY, LOSS OF PROFITS OR REVENUE, LOSS OF THE UNIT, LOSS OF TIME, OR INCONVENIENCE.

This warranty applies to units sold in the United States. Any units sold elsewhere are warranted by the affiliated marketing company of NESLAB Instruments, Inc. This warranty and all matters arising pursuant to it shall be governed by the law of the State of New Hampshire, United States. All legal actions brought in relation hereto shall be filed in the appropriate state or federal courts in New Hampshire, unless waived by NESLAB.